



**Canada-Wide
Parts Distributors Ltd. ®**

August 24, 2012

Technical Update

GM 8.5/8.6" Open Nest Kit and Case

1982-1998

Empty diff case - 26010481 (OE Cast # 26013855)
Nest Kit - 28 spl - GM10-SPGK28 (1982-89)
Nest Kit - 30 spl - GM10-SPGK30 (1990-98)
Overhaul Kit - R10

1999 – mid 2000

Empty diff case - 26060748* (OE Cast # 0748, 0749)
Nest Kit - 30 spl - GM10-SPGK30-99
Overhaul Kit - R10K

mid 2000 – 2008

Empty diff case - 40007876* (OE Cast # 7875, 1073)
Nest Kit - 30 spl - GM10-SPGK30-00
Overhaul Kit - R10K

2009 Up

Loaded diff case - 40048044 (OE Cast # 8064)
Nest Kit - 30 spl - GM10-SPGK30-09
Overhaul Kit - R10Q

NOTES:

*The earlier design empty cases 40007876 & 26060748 are no longer available separately. You have to purchase the later design Loaded case 40048044. The loaded 40048044 will fit all years from 1999 up to 2012.

You can only use the earlier nest kits GM10-SPGK30-99 and GM10-SPGK30-00 with their respective year empty cases. See OE Casting numbers listed above. If you try to install in a different year/generation case they will not fit properly (either too tight or too loose).

GM10-SPGK30-09 nest kit will only fit 2009 and up cases with Cast # 8064.

If you have any questions please don't hesitate to contact your branch for assistance

EDMONTON

15745 - 118 Avenue
Tel: (780) 454-5115
Toll-Free: 1-800-665-7671

MISSISSAUGA

1261A Shawson Drive
Tel: (905) 564-3116 Toll-Free: 1-877-564-3116
www.canadawideparts.com

SURREY

#1, 18771 - 96 Avenue
Tel: (604) 881-0205
Toll-Free: 1-877-560-0287